




**7450.0820**

Onderdelen informatie  
Erzatzteil information  
Spare part information  
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1		BODY	1
2		BOTTOM FRAM SUPPORT	1
3		BODY FRAM STRIP	1
4		HEATER CLIP	1
5		FRONT BOARD	1
6		EVAPORATOR	1
7		CIRCLE FAN COVER	1
8	CS9999.0136	CIRCLE FAN	2
9		PROBE CLIP	1
10	CS9181.2050	SENSOR	2
10a	CS9993.2448	SENSOR	2
11		INNER BOTTOM BOARD	2
12		SHELF SUPPORT MIDDLE	2
12a		SHELF SUPPORT MIDDLE/LEFT	1
13		SHELF SUPPORT BACK	2
14		SHELF SUPPORT FRONT	2
15		SHELF HOLDER MIDDLE	2
15a		SHELF HOLDER MIDDLE/LEFT	1
16		LEM LIGHT	3
17		PRICE CLIP HOLDER	2
18		PRICE CLIP	2
19		GLASS SHELF MIDDLE	2
20		Hex Domed Cap Nut	6
21		Hex Domed Cap plate	6
22		Hex Domed Cap cover	6
23		RIGHT GLASS	1
24		PILLAR RIGHT	1
25		CONDUCT BOARD STRIP	1
26		CONDUCT BOARD	1
27		Side Glass Seal Gasket	2
28		Top Glass Seal Gasket	1
29		CURVED GLASS CLIP	1
30		Front Glass	1
31		Pillar Left	1
32		Left Glass	1
33		SUPPORT HOLDER RIGHT	1
34		SUPPORT HOLDER LEFT	1
35	CS9338.2770	Door Gasket	2
36		Door Frame	1
37		GUIDE 2	2
38		GUIDE 1	2
39		Front Door	1
40		Back Door	1

POS:	Art.No.:	Omschrijving:	Aantal:
41		HANDLE	2
42		ROLLER	4
43		BLOCK BUTTON	1
44		DRAIN PIPE	1
45		DRIAN PIPE CONNACTOR	1
46		LEFT BOARD	1
47		EVAPORATE PIPE	1
48		WATER BOX PROTECTOR	1
49		WATER BOX	1
50	CS9390.0130	CONDENSER FAN	1
51		CONDENSER GRILL	1
52		CONDENSER FAN BLADE	1
53	CS9338.1375	CONDENSER	1
54		FILTER DRYER	1
55		SUCTION PIPE	1
56		BACK GRILL	1
57		PLUG	1
58		THERMOSTAT BOX COVER	1
59		THERMOSTAT BOX	1
60		CONTROL PANEL	1
61		Unit Board	1
62		COMPRESSER	1
65		SWITCH	1
66	CS9338.3545	THERMOSTAT DISPLAYER	1
67		ELECTRIC DEVICE BOX	1
70		LED POWER	1
71		FEET	2
72	CS9338.2558	WHEEL	4
73		RIGHT BOARD	1
74		FRAME	1
75		FRONT GRILL	1
76		Top Lamp Support	1
77		Top	1
78		Top Glass	1