



7455.2110


Onderdelen informatie


Erzatzteil information


Spare part information

Information de pièces









Onderdelenlijst 7455.2110

POS:	Art.No.:	Omschrijving:	Aantal:
1-1A	9338.1844	Canopy top and bottom frame(black)	1
1-2		Canopy perspex cover	1
1-3		Left door(black)	1
1-4		Right door(black)	2
1-5	9338.2244	Door sealer(black)	3
1-6	9338.1833	Door handle(black)	1
1-7	9338.1843	Front grill panel(black)	1
1-7A	9338.1843	Front grill panel(black) for digital controller	1
1-8	9338.1905	K clips	53
1-9		Shelf A	8
1-10		Shelf B	4
1-11		Back ventilation right	1
1-12		Back ventilation left	1
1-13		Castor without brake	3
1-14		Castor with brake	3
2-1	9338.1902	T5 LED light	1
2-2	9095.0040	Switch (black)	1
2-3	9338.1836	P shape LED light right	1
2-4	9338.1831	P shape LED light left	1
2-5		T5 LED light	2
2-6		Electrical wiring box	1
2-7	9338.1837	LED transformer LPV-60-24	1
2-8	9338.1838	Defrost timer 15min.	1
2-9		Power plug	1
3-1	9338.1920	Evaporator	1
3-2	9338.1839	Evaporator fan motor	2
3-3		Evaporator fan motor bracket	8
3-4	9338.1885	Evaporator fan blade	2
3-5		Evaporator fan motor panel	1
3-6		Evaporator fan motor cover	2
3-7		Thermometer	1
3-8	9338.1900	Mechanical controller	1
3-9	9338.1900	Mechanical controller knob	1
3-10		Drainage	1
3-11		Drainage connector	1
3-12		Dry filter	1
3-13	9338.2282	Water tray	1
3-14	9338.1846	Compressor	1
3-15		Condenser fan motor bracket	2
3-16	9338.1841	Condenser fan motor	2
3-17	9338.1855	Condenser fan blade	2
3-18	9338.1842	Condenser	2